

Material Comparisons

We live in a fantastic world to have literally hundreds of colors available in dozens of different materials for hobby 3D printing

TPU "*Thermoplastic PolyUrethane*", TPE "*ThermoPlastic Elastomer*", Flexible-PLA, etc.

- Softest material straight from a filament printer
 - Has more in common with rubber than plastic
 - Best impact resistance
 - Adequate temperature resistance
 - Innate flexibility allows its use well above the glass transition temperature
 - Moisture
 - **TPU and TPE filaments MUST be dry!**
 - Moist filament has horrible print quality
 - Weaknesses are created in each layer by Steam bubbles
 - Uses
 - Anything that needs to be flexible or survive regular & significant impacts
 - If the low temp and flexibility aren't problems, this can be used in place of many other plastics
 - Issues
 - Flexibility, stretch, compression, etc. are REAL problems for some extruder styles
 - Bowden systems can usually deal down to 95a shore hardness materials if printed SUPER S L O W
 - Multi-Material systems can RARELY deal with 95a materials (MMU, Palette, AMS, etc.)
 - My Opinions
 - Medium to poor aesthetic print quality when compared to other filament materials
 - Printing flexible materials can offer many new possibilities for home 3D printers
 - Rubber mallet, corner bumpers, cane tips, protective cases, etc.
-

ABS "Acrylonitrile Butadiene Styrene"

- Requires higher temperature "All Metal" hot end
- Negative issues
 - Warping - Ambient closer to Tg helps
 - Possible layer delamination- Ambient closer to Tg helps
 - Noxious off-gassing - Enclosed printing with internal carbon filter or after-print venting helps
- Prefers enclosure/print chamber to be kept around half it's glass transition point (~50c)
- Any plastic containing Styrene stinks when printing and reacts with Acetone

• Post-processing

- Can be Vapor Smoothed using Acetone for glassy smooth prints
- Sands nicely by machine if kept cool, sanding by hand can be dusty
 - Recommend wet sanding when possible
- Painting protects the plastic from UV deterioration and fills in layer lines

• My Opinions

- Mostly seal a 3d printer into an enclosure to keep both Heat and Stink inside while printing
 - Thin nylon photography tents might be OK if the room is already REALLY warm but they loose heat quickly
 - Thin plastic sheeting works better than nylon but suffers from poor insulation qualities if ambient temp is cool
 - Large cardboard box worked great but I didn't like unfolding the flaps to touch printer each time
 - IKEA LACK table with foam-core craft board walls/door made for excellent insulation
-

ASA "Acrylonitrile Styrene Acrylate"

- Requires higher temperature "All Metal" hot end
- Negative issues
 - Warping - Ambient closer to Tg helps
 - Possible layer delamination- Ambient closer to Tg helps
 - Noxious off-gassing - Enclosed printing with internal carbon filter or after-print venting helps
- Prefers enclosure/print chamber to be kept around half it's glass transition point (~50c)
- Any plastic containing Styrene stinks when printing and reacts with Acetone

• Post-processing

- Can be Vapor Smoothed using Acetone for glassy smooth prints
- Sands nicely by machine if kept cool, sanding by hand can be dusty
 - Recommend wet sanding when possible
- Painting protects the plastic from UV deterioration and fills in layer lines

• My Opinions

- Mostly seal a 3d printer into an enclosure to keep both Heat and Stink inside while printing
 - Thin nylon photography tents might be OK if the room is already REALLY warm but they loose heat quickly
 - Thin plastic sheeting works better than nylon but suffers from poor insulation qualities if ambient temp is cool
 - Large cardboard box worked great but I didn't like unfolding the flaps to touch printer each time
 - IKEA LACK table with foam-core craft board walls/door made for excellent insulation
-

PLA "PolyLactic Acid", PLA+, PLA-Pro, etc.

- Stiffest material
 - Generally bends less easily than other materials
- Hardest material
 - Resists deformation by a pointy thing better than most (at least to start with...)
- Very poor temperature resistance
 - Prints left in a hot car will likely deform
- Very poor impact resistance
 - PLA Hammer + Nail = Plastic Shrapnel
- Very poor creep resistance
 - PLA shelf bracket + (insert time) = Shelf on floor
 - I use PLA for a ton of things, but when it MUST hold weight, I use PC or PA depending on impact requirement
- "+" and "Pro" modifiers vary wildly between manufacturers
 - **Test EVERY new material;** Make no assumptions about the modifiers or their expected properties

• Deterioration

- Increased stringing with more moisture typically, but usually very mild compared to PETG, TPU, etc.
- Embrittlement with extended moisture or Ultraviolet light exposure

- These traits seem to follow the base material rather than the additives or colorants
- Some transparent, translucent, or silk filaments seemed to be significantly less affected

• Post-processing

- Sanding PLA is *SLOW!* - If sanded too briskly the dust melts back onto the part, ruining the surface
- 3D Gloop is the only "consumer accessible" smoothing agent for PLA - Industrial chemicals are available
- Painting protects the plastic from UV deterioration and fills in layer lines
 - Lighter colors absorb less heat
 - Glossy finishes absorb less heat

• Uses

- Anything that will live inside a home (No UV and low heat)
- No large physical stresses placed upon it (Creeping over time)

• Known Exceptions (to the normal rules)

- Protopasta HTPLA (*High Temperature Polylactic Acid*)
 - Prints like normal PLA then heat treated at increasing temperatures to get ~100c heat deflection temp!
 - Warpage during heat treat process can be an issue for some part geometries
 - <https://proto-pasta.com/pages/high-temp-pla>
- Lay-Filaments Reflect-O-Lay Flexible PLA
 - Prints and physically acts like soft (<90) TPU/TPE
 - Feels somewhat "fuzzy" and a lot like rubber
 - Crazy retroreflector effect
 - <http://lay-filaments.com/LayFilaments-Overview+LightMeta5-b.pdf>

• My Opinions

- Best for aesthetic print quality
- Seems to "creep" under any significant stresses
- Favorite material for prototyping \$\$\$ (*prototypes become finished products when they work the first time*)

PETG, PETG+, PETG-Pro, etc.

- Prints on most printers capable of PLA

- Adequate temperature resistance
-

PC

- Requires higher temperature "All Metal" hot end
 -
-

PP

- Requires higher temperature "All Metal" hot end
 -
-

PA, Nylon, etc.

- Requires higher temperature "All Metal" hot end
 -
-

PE

- Requires higher temperature "All Metal" hot end
 -
-

More to come...

Revision #27

Created 30 August 2023 16:08:20 by smokintbird

Updated 4 May 2024 13:35:28 by smokintbird